


Gasketed plate heat exchangers

Industrial line - T35, TS35, TL35, T45, T50, TS50, WideGap 350



Lit. Code 200000421-4-EN-GB Instruction Manual

BRITISH ENGLISH

Published by

Alfa Laval Lund AB Box 74 Visit: Rudeboksvägen 1 226 55 Lund, Sweden +46 46 36 65 00 +46 46 30 50 90 info@alfalaval.com

The original instructions are in English

© Alfa Laval Corporate AB 2021-04

This document and its contents are subject to copyrights and other intellectual property rights owned by Alfa Laval Corporate AB. No part of this document may be copied, re-produced or transmitted in any form or by any means, or for any purpose, without Alfa Laval Corporate AB's prior express written permission. Information and services provided in this document are made as a benefit and service to the user, and no representations or warranties are made about the accuracy or suitability of this information and these services for any purpose. All rights are reserved.



English

Download local language versions of this instruction manual from www.alfalaval.com/gphe-manuals or use the QR code

български

Изтеглете версиите на това ръководство за употреба на местния език от www.alfalaval.com/gphe-manuals или използвайте QR кода.

Český

Stáhněte si místní jazykovou verzi tohoto návodu k obsluze z www.alfalaval.com/gphe-manuals nebo použijte QR kód.

Dansk

Hent lokale sprogversioner af denne brugervejledning på www.alfalaval.com/gphe-manuals eller brug QRkoden.

Deutsch

Sie können die landessprachlichen Versionen dieses Handbuch von der Website www.alfalaval.com/gphemanuals oder über den QR-Code herunterladen.

ελληνικά

Πραγματοποιήστε λήψη εκδόσεων του παρόντος εγχειριδίου οδηγιών σε τοπική γλώσσα από το www.alfalaval.com/gphe-manuals ή χρησιμοποιήστε τον κωδικό QR.

Español

Descárguese la versión de este Manual de instrucciones en su idioma local desde www.alfalaval.com/gphe-manualso utilice el código QR.

Eesti

Selle kasutusjuhendi kohaliku keele versiooni saate alla laadida lingilt www.alfalaval.com/gphe-manuals või kasutades QR-koodi.

Suomalainen

Laitaa tämän käyttöohjeen suomenkielinen versio osoitteesta www.alfalaval.com/gphe-manuals tai QR-koodilla.

Français

Téléchargez des versions de ce manuel d'instructions en différentes langues sur www.alfalaval.com/gphemanuals ou utilisez le code QR.

Hrvatski

Preuzmite lokalne verzije jezika ovog korisničkog priručnika na poveznici www.alfalaval.com/gphemanuals ili upotrijebite QR kod.

Magyar

Az On nyelvére lefordított használati útmutatót letöltheti a www.alfalaval.com/gphe-manuals weboldalról, vagy használja a QR-kódot.

Italiano

Scarica la versione in lingua locale del manuale di istruzioni da www.alfalaval.com/gphe-manuals oppure utilizza il codice QR.

日本の

www.alfalaval.com/gphe-manuals からご自分の言語の 取扱説明書 をダウンロードするか、QR コードをお使 いください。

한국의

www.alfalaval.com/gphe-manuals 에서 이 사용 설명서 의 해당 언어 버전을 다운로드하거나 QR 코드를 사용 하십시오.

Lietuvos

Lejupielādējiet šīs rokasgrāmatas lokālo valodu versijas no vietnes www.alfalaval.com/gphe-manuals vai izmantojiet QR kodu.

Latvijas

Atsisiųskite šios instrukcijos versijas vietos kalba iš www.alfalaval.com/gphe-manuals arba pasinaudokite QR kodu.

Nederlands

Download de lokale taalversies van de instructiehandleiding vanaf www.alfalaval.com/gphemanuals of gebruik de QR-code.

Norsk

Last ned denne instruksjonshåndboken på lokalt språk fra www.alfalaval.com/gphe-manuals eller bruk QR-koden.

Polski

Pobierz lokalne wersje językowe tej instrukcji obsługi z www.alfalaval.com/gphe-manuals lub użyj kodu QR.

Português

Descarregue as versões locais na sua língua deste manual de instruções a partir de www.alfalaval.com/gphe-manuals ou use o código QR.

Português do Brasil

Faça download das versões deste manual de instruções no idioma local em www.alfalaval.com/gphe-manuals ou use o código QR.

Românesc

Versiunile în limba locală ale acestui manual de instrucţiuni pot fi descărcate de pe www.alfalaval.com/gphe-manuals sau puteţi utiliza codul QR.

Русский

Руководство пользователя на другом языке вы можете загрузить по ссылке www.alfalaval.com/gphe-manuals или отсканировав QR-код.

Slovenski

Prenesite različice uporabniškega priročnika v svojem jeziku s spletne strani www.alfalaval.com/gphemanuals ali uporabite kodo QR.

Slovenský

Miestne jazykové verzie tohto návodu na používanie si stiahnite z www.alfalaval.com/gphe-manuals alebo použite QR kód.

Svenska

Ladda ned lokala språkversioner av denna bruksanvisning från www.alfalaval.com/gphe-manuals eller använd QR-koden.

中国

从 www.alfalaval.com/gphe-manuals 或使用 QR □下□此使用□ 明□的本地□言版本。

Contents

1	Introduction7					
	1.1	Intended use	7			
	1.2	Reasonably foreseeable misuses	7			
	1.3	Prior knowledge	7			
	1.4	Delivered technical information	8			
	1.5	Warranty conditions	8			
	1.6	Advice	8			
	1.7	Environmental compliance	g			
2	Safety1					
	2.1	Safety considerations	11			
	2.2	Definitions of expressions	11			
	2.3	Personal protective equipment	12			
	2.4	Working at height	13			
3	Description					
	3.1	Components	15			
	3.2	Name plate	17			
	3.3	A measure	19			
	3.4	Function	20			
	3.5	Multi-pass	21			
	3.6	Identification of plate side				
4	Installation2					
	4.1	Before installation, lifting and transport	23			
	4.2	Requirements	25			
	4.3	Securing the heat exchanger before lifting				
	4.4	Crate handling	28			
		4.4.1 Crate — Inspection	29			
		4.4.2 Lifting and transportation	29			
	4.5	Unpacking the crate	31			
		4.5.1 Manufactured sides — Opening	32			
		4.5.2 Flip box — Opening	33			
		4.5.3 Crafted sides — Opening	34			
		4.5.4 Inspection after uncrating	35			
	4.6	Lifting the equipment	36			
	4.7	Raising	42			
	4.8	Inspection before installation	44			
5	Operation4					
	5.1	Start-up	45			

	5.2 Unit in operation				
	5.3	Shut-d	down	47	
6	Mai	49			
	6.1	Cleani	50		
	6.2		52		
		6.2.1	Bolt configuration	52	
		6.2.2	Opening procedure	52	
	6.3	Manua	al cleaning of opened units	57	
		6.3.1	Deposits removable with water and brush	57	
		6.3.2	Removal, lifting and insertion of plates in the field	58	
		6.3.3	Deposits not removable with water and brush	58	
	6.4	Closin	60		
	6.5	Pressu	63		
	6.6	6.6 Regasketing			
		6.6.1	Clip-on / ClipGrip	64	
		6.6.2	Base-ad gaskets	65	
		6.6.3	Glued gaskets	65	
7	Sto	67			
	7.1	•	67		
	7.2	_	68		

1 Introduction

This manual provides information needed to install, operate and carry out maintenance of your gasketed plate heat exchangers.

The following models are covered in this manual:

- T50
- TS50
- T45
- T35
- TS35
- TL35
- WideGap 350

1.1 Intended use

The intended use of this equipment is to transfer heat in accordance with a decided configuration.

All other use is prohibited. Alfa Laval will not be held responsible for injury or damage if the equipment is used for any other purpose than the intended use described above.

1.2 Reasonably foreseeable misuses

- Do not lift or transport the crate nor the equipment in any other way than stated in this instruction manual.
- Connect a pipe in the way it is meant to be connected to the plate heat exchanger. Gasket and lining can be damaged if a pipe is connected in the wrong way.
- On semi-welded units it is a safety issue if the wrong pipe is connected to the wrong port, double check that the correct media is connected to the correct port according to the PHE drawings.
- It is a risk to damage the hangers if you hang in or move many plates at a time. It is recommended to handle one or a few plates at a time.
- When setting the A measure, always tighten the bolts crosswise, evenly, and a little at a time to avoid diagonal shifting and snaking. For information regarding the A measure, see Section A measure in the Chapter Description.
- After a stop, increase the flow gently to avoid deformed plates.
- At a start, raise the temperature gently to avoid cracks in the gaskets or create a blow-out.

1.3 Prior knowledge

The plate heat exchanger shall be operated by persons who have studied the instructions in this manual and have knowledge of the process. This includes knowledge of precautions regarding media type, pressures, temperatures in the plate heat exchanger as well as specific precautions required by the process.

Maintenance and installation of the plate heat exchanger shall be done by persons who have knowledge and authorization according to local regulations. This may include actions such as piping, welding and other kind of maintenance.

For maintenance actions not described in this manual, contact your Alfa Laval representative for advice.

1.4 Delivered technical information

For the manual to be considered complete, the following delivered documentation must be accessible to the users of this instructions manual:

Declaration of Conformity

Spare parts list

A bill of material as the equipment is built.

Plate hanging list

A description of the channel plate installation.

Technical specification

Connection information, measurements, and section information.

Plate heat exchanger (PHE) drawing

A drawing of the delivered plate heat exchanger.

The weight of the delivered plate heat exchanger as well as all dimensions can be found on the delivered PHE drawing.

The listed documents are unique for the delivered product (equipment serial number). Instructions shall be accompanied, where appropriate, by the technical documents, drawings and diagrams necessary for a full understanding of these instructions.

The PHE drawing mentioned in this manual are the drawings included in the delivery.

1.5 Warranty conditions

The warranty conditions are usually included in the signed sales contract prior to the order of the delivered plate heat exchanger. Alternatively, the warranty conditions are included in the sales offer documentation or with a reference to the document specifying the valid conditions. If faults occur during the specified warranty period, always consult your local Alfa Laval representative for advice.

Report to the local Alfa Laval representative, the date when the plate heat exchanger was put into operation .

1.6 Advice

Always consult your local Alfa Laval representative for advice on:

- · New plate pack dimensions if you intend to change the number of plates
- Selection of gasket material if operating temperatures and pressures are permanently changed, or if another medium is to be processed in the plate heat exchanger

8 200000421-4-EN-GB

1.7 Environmental compliance

Alfa Laval endeavours to perform its own operations as cleanly and efficiently as possible, and to take environmental aspects into consideration when developing, designing, manufacturing, servicing and marketing its products.

Waste management

Separate, recycle, or dispose of all material and components in a safe, and environmentally responsible way, or according to national legislation or local regulations. If there is any uncertainty regarding what material a component is made of, contact the local Alfa Laval sales company. Use a certified (ISO 14001 or similar) scrapping or waste handling company.

Unpacking

Packing material consists of wood, plastics, cardboard boxes and, in some cases, metal straps.

- Wood and cardboard boxes can be reused, recycled or used for energy recovery.
- Plastics should be recycled or burnt at a licensed waste incineration plant.
- Metal straps should be sent for material recycling.

Maintenance

- · All metal parts should be sent for material recycling.
- Oil and all non-metal wear parts must be taken care of in accordance with local regulations.


Scrapping

At end of use, the equipment shall be recycled according to relevant, local regulations. Besides the equipment itself, any hazardous residues from the process liquid must be considered and dealt with in a proper manner. When in doubt, or in the absence of local regulations, please contact the local Alfa Laval sales company.

10 200000421-4-EN-GB

2 Safety

2.1 Safety considerations



The plate heat exchanger should be used in accordance with the specified configuration of material, media types, temperatures and pressure for your specific plate heat exchanger

2.2 Definitions of expressions



Type of hazard

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION Type of hazard

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.




NOTE indicates a potentially hazardous situation which, if not avoided, may result in property damage.

Safety

2.3 Personal protective equipment

Protective shoes







Protective helmet

Any helmet designed to protect the head from accidental injury.



Protective goggles

A pair of tight-fitting eyeglasses worn to protect the eyes from hazards.



Protective gloves

Gloves that protects the hand from hazards.



12 20000421-4-EN-GB

2.4 Working at height

If the installation requires working at a height of two meters or higher, safety arrangements must be taken in consideration.






Risk of falling.

For any kind of work at height, always ensure that safe means of access is available and used. Follow local work at height regulations and guidelines. Use scaffolds or a mobile work platform and a safety harness. Create a safety perimeter around the working area and secure tools or other objects from falling.



3 Description

3.1 Components



Main components

1. Frame plate

Fixed plate with a various number of portholes for the connection of the piping system. The carrying and guiding bar are attached to the frame plate.

2. Carrying bar

Carries the plate pack and the pressure plate

3. Plate pack

Heat is transferred from one media to the other through the plates. The plate pack consists of channel plates, end plates, gaskets and in some cases transition plates.

4. Pressure plate

Moveable plate that can contain a various number of portholes for the connection of the piping system.

5. Guiding bar

Keeps the channel plates, connection plates and the pressure plate aligned at their lower end

6. Support column

Supports carrying and guiding bars.

7. Tightening bolts

Compress the plate pack between the frame plate and the pressure plate.

The bolts with bearing boxes are identified as tightening bolts.

Remaining bolts are used as locking bolts.

8. Portholes

Portholes through the frame plate allow the media to enter into or exit from the plate heat exchanger.

Connections

· Stud bolts

Threaded stud bolts around the portholes secure the flange connections to the apparatus.

Multi-section

Partition plates

Solid carbon steel plates used in multi-pass configurations. Strengthens the turning plate when needed.

Optional components

Foot

Gives stability and is used to secure the plate heat exchanger with bolts to the foundation.

Protection sheets

Cover the plate pack and protect against leakage of hot or aggressive fluids and the hot plate pack.

· Bolt protection

Plastic tubes that protect the threads of the tightening bolts.

Insulation

For applications where the plate heat exchanger surface will be hot or cold, insulation can be used.

· Lifting device

Separate device that are attached on the plate heat exchanger used for lifting the plate heat exchanger.

Earthing lug

An earthing connection is used to eliminate the risk of static electricity building up in the equipment.

Nozzle cover

Protection to avoid particles to enter into the plate heat exchanger during transportation.

Drip tray

Depending on the type of fluid in the plate heat exchanger and the type of installation, a drip tray (drainage box) may be necessary to avoid injury to personnel and damage to equipment.

Securing lifting or transportation

Locking device fastened between the frame and the pressure plate. Valid for models T50 and TS50.

16 20000421-4-EN-GB

3.2 Name plate

The type of unit, manufacturing number and manufacturing year can be found on the name plate. Pressure vessel details in accordance with the applicable pressure vessel code are also given. The name plate is fixed to the frame plate, most commonly, or the pressure plate. The name plate can be a steel plate or a sticker label.

WARNING

Risk of damage to equipment.

The design pressures and temperatures for each unit are marked on the name plate. These must not be exceeded.



Risk of damage to equipment.

Avoid aggressive chemicals for cleaning the plate heat exchanger when a sticker label is used.

The design pressure (11) and the design temperature (10), as given on the name plate, are the values against which the plate heat exchanger is approved according to the pressure vessel code in question. The design temperature (10) may exceed the maximum operating temperature (8) for which the gaskets have been selected for. If the operating temperatures as specified on the PHE drawing are to be changed the supplier should be consulted.

- 1. Space for logotype
- 2. Open space
- 3. Website for service
- 4. Drawing of possible locations of connections/Location of 3A tag for 3A units
- 5. Space for mark of approval
- 6. Warning, read manual
- 7. Date of pressure test
- 8. Maximum operating temperature
- **9.** Manufacturer test pressure (PT)
- 10. Allowable temperatures Min/Max (TS)
- 11. Allowable pressures Min/Max (PS)
- 12. Decisive volume or volume for each fluid (V)
- 13. Locations of the connections for each fluid
- 14. Decisive fluid group
- 15. Year of manufacture
- 16. Serial number
- **17.** Type
- 18. Manufacturer's name

200000421-4-FN-GB





Figure 1: Example of metallic name plate to the left and sticker label name plate to the right

18 20000421-4-EN-GB

3.3 A measure

The **A** measure is the distance from the frame plate (1) to the pressure plate



3.4 Function

The plate heat exchanger consists of a pack of corrugated metal plates with portholes for the input and output of the two separate fluids. The heat transfer between the two fluids takes place through the plates.

The plate pack is assembled between a frame plate and a pressure plate and compressed by tightening bolts. The plates are fitted with a gasket which seals the channel and directs the fluids into alternate channels. The plate corrugation promotes fluid turbulence and supports the plates against differential pressure.




Figure 2: Example of a single-pass set up.

20 200000421-4-EN-GB

3.5 Multi-pass

Multi-pass sections can be created by using turning plates with 1, 2 or 3 unholed ports. The main purpose is to change the flow direction of one or both fluids.

An example of where multi-pass can be used is in processes that require longer heating periods if the media requires slower heating.




Figure 3: Example of a multi-pass set up.


- 1. End plate II
- 2. Channel plates
- Transition plate
- Turning plate
- 5. Partition plate

3.6 Identification of plate side

The A side of the plates (symmetric pattern) are identified by a stamp with the letter A and the model name at the top of the plate (see the image 1 below).

Plates with asymmetric pattern has two possible sides for placement of the gaskets. The pattern is marked A W for the wide-side image 2 and B N for normal-side image 3.

Plates with WideGap pattern has two possible sides for placement of the gaskets. The pattern is marked A R for the wide-side (Ridge) image 2 and B V for normal-side (Valley) image 3.



22 200000421-4-EN-GB

4 Installation

4.1 Before installation, lifting and transport

CAUTION

Risk of damage to equipment.

During installation or maintenance, precautions must be taken to avoid damaging the plate heat exchanger and its components. Damage to components can adversely affect the performance or serviceability of the plate heat exchanger.



Risk of personal injury.

The equipment is heavy.

Never lift or move the equipment manually.

To consider before installation

- Keep the plate heat exchanger packed until installation.
- Before connecting any piping, make sure all foreign objects have been flushed out of the piping system that should be connected to the plate heat exchanger.
- Before connecting any piping, make sure that all the bolts for the feet are tightened and that the plate heat exchanger is firmly fixed to the foundation.
- Before start-up, check that all the tightening bolts are firmly tightened and that the plate pack has the correct measurements. See the PHE drawing.
- When connecting the piping system, make sure the pipes do not subject the plate heat exchanger to stress or strain.
- · Avoid vibration, install any anti-vibration equipment if necessary.
- The plate heat exchanger connections on the follower and connector grids have little strength against pipe work or nozzle loads. Such loads can arise for example from thermal expansion. Proper care must be taken to avoid transfer of such pipe forces and moments to the plate heat exchanger.
- To avoid water hammer, do not use fast-closing valves.
- Make sure that no air remains inside the plate heat exchanger.
- Safety valves shall be installed according to current pressure vessel regulations.
- It is recommended that protection sheets are used to cover the plate pack.
 Protect against the leakage of hot or aggressive fluids and the hot plate pack.
- If the plate heat exchanger surface temperature is expected to be hot or cold, take protective actions, such as insulate the plate heat exchanger, to avoid risk for personnel injuries. Always ensure that required actions are according to local regulations.
- Design pressures and temperatures for each model are marked on the name plate. These shall not be exceeded.


- Follow the hierarchy specified in this presentation.
- · Check the condition of the flooring.
- · Always complete a risk assessment.
- Use frames and equipment designed for the task.
- Always check the center of gravity before unpacking or moving the equipment. Keep the center of gravity as low as possible.
- · Always move slow and steady.

Risk assessment

Always perform a thorough risk assessment before lifting and transporting the crated or uncrated equipment on every handling occasion.

24 200000421-4-EN-GB

4.2 Requirements



Space

See the delivered PHE drawing for actual measurements.

- **1.** Free space is required for lifting plates in and out.
- 2. Free space is required for removing the tightening bolts. The size is depending on the length of the tightening bolts.
- 3. Free space is required under the lower tightening/locking bolt for maintenance.
- **4.** Supports for the guiding bar may be needed.
- 5. Do not use fixed pipes or other fixed parts like feet, fasteners etc. inside the shaded area.

Foundation

Install on a flat foundation designed for the equipment weight.

Elbow

To make it easier to disconnect the plate heat exchanger, an elbow should be fitted to the connection in the pressure plate, directed upwards or sideways, and with another flange located just outside the contour of the plate heat exchanger.

Shut-off valve

To be able to open the plate heat exchanger, shut-off valves should be provided in all connections.

Connection

Different types of connections can be used to connect the piping system to the apparatus. Flanged connections shall be attached with pin bolts.

Avoid excessive loads from the piping system.

Connections in the pressure plate

It is important that the plate pack has been tightened to the correct **A** measure (check against the PHE drawing) before the piping system is connected.

If necessary, adjust the **A** measure.

Drip tray (optional)

Depending on the type of fluid in the plate heat exchanger and the type of installation, a drip tray (drainage box) may be necessary to avoid injury to personnel and damage to equipment.



Put the drip tray in place before positioning the plate heat exchanger.


Required personnel

The installation and handling of the plate heat exchanger requires at least two persons.

26 20000421-4-EN-GB

4.3 Securing the heat exchanger before lifting

Secure the heat exchanger before lifting or transportation. Instruction below are valid for both the T50 and the TS50.



- 1. Fasten the locking device securely between the frame plate and the pressure plate.
- 2. Fasten the locking bracket to secure the pressure plate to the carrying bar.
- **3.** Fasten the locking bracket to secure the pressure plate to the guiding bar.

4.4 Crate handling



Risk of personal injury.

Lifting and transport of the crated and uncrated equipment must be carried out by skilled persons. See *Prior knowledge* in Chapter *Preface*.

The plate heat exchanger is delivered on a pallet and can be packed in a crate or wrapped in stretch film. There are three main versions of crates:

- Manufactured sides sides and a top made in separate pieces
- Flip box a box with hinges in the sides and a loose top
- Crafted sides sides and top crafted board by board when packed for delivery

The centre of gravity is marked on the crate or the wrapping.

A crate is also marked with other symbols according to the table.

Symbol	Meaning
+++	Centre of gravity
↑ <u>*</u>	Do not stack on top
Ī	Fragile
	This way up

28 200000421-4-EN-GB

4.4.1 Crate — Inspection

Examine the outside of the crates before starting to unload and report any transport damage. Contact the insurance company in case of any damages.

4.4.2 Lifting and transportation

WARNING Risk of personal injury.

The equipment is heavy and sensitive and must be handled with precaution.

Unauthorized personnel is not allowed to be in the defined risk area when the crated or uncrated equipment is handled.

WARNING Risk of damage to equipment.

The crate is not designed to stand the force from hoist slings pressing on the top of the crate.

Always use a forklift to lift and transport the crated equipment.

WARNING Risk of personal injury.

Never work under hanging load.

WARNING Risk of personal injury.

Always use a forklift approved for the load and in accordance with local regulations.

Labels, symbols, and warning placards are located on the external surfaces of the crates and outline the handling principles which must be observed.

- Never leave a hanging load unattended.
- When the equipment, crated or uncrated, is assembled with the delivered pallet it must be lifted using a forklift.
- Plan the lifting and the transportation thoroughly.
- Define the risk area for lifting and transport of the crated or uncrated equipment.
- Always perform a risk assessment of the risk area and transport ways before lifting and transporting the crated or the uncrated equipment.
- The crates should not be subjected to sudden shocks or movement. The crates are not load bearing and must not be stacked or have other items placed on them.
- The crates should be kept in the indicated upright position.
- · Lift the crates as instructed. Lift only enough to clear the floor.
- · Lift and transport the load slowly and gently.
- Crated equipment must be lifted in the pallet using a forklift.
- The length of the forklift forks should be equal to, or longer than, the depth of the pallet.
- Make sure that the crate remains stable on the lifting equipment.

200000421-4-FN-GB 29

- Move the crate to its destination.
- Lower the crate gently to the floor, leaving enough room around it for easy access to all sides.
- Make sure that the crate is firmly supported. Place blocks or plates under it if required.
- When working under a hanging load, for example when assembling the stands, you must secure the load from falling on you using wooden beams or likewise.
- The centre of gravity must always be between the forklifts forks.


Labels that will indicate if the crates have been tipped over or exposed to extremes of humidity can be put on the crates or the equipment.

30 20000421-4-EN-GB

4.5 Unpacking the crate

Follow the procedure for the corresponding type of crate::

- Manufactured sides See Procedure Manufactured sides Open
- Flip box See Procedure Flip box Opening
- Crafted sides See Procedure Crafted sides Opening



Unpacking area

The minimum unpacking area must be at least twice the size of the largest crate.

When the crate is removed but the equipment is still assembled with the pallet, remove any loose parts or smaller parts assembled with the pallet.

Equipment can be assembled with the pallet with plastic bands or with screws. Plastic bands are cut off. Screws are removed.


4.5.1 Manufactured sides — Opening

WARNING Risk of personal injury.


The equipment or loose objects can fall. Plastic straps may snap when cut off. There can be sharp edges, splinters, and nails on the crate and the equipment.

Wear personal protective equipment when handling the equipment during unpacking and installation. Handle the equipment with precaution. See Section *Personal protective equipment* in Chapter *Safety*.

Cut the plastic bands off and remove the top of the crate.



Disassemble the sides by removing the screws or the nails.



32

4.5.2 Flip box — Opening


WARNING

Risk of personal injury.


The equipment or loose objects can fall. Plastic straps may snap when cut off. There can be sharp edges, splinters, and nails on the crate and the equipment.

Wear personal protective equipment when handling the equipment during unpacking and installation. Handle the equipment with precaution. See Section Personal protective equipment in Chapter Safety.

Cut the plastic bands off and remove the top of the crate.



Lift the flipbox up and remove it from the pallet.



4.5.3 Crafted sides — Opening

MARNING


Risk of personal injury.

The equipment or loose objects can fall. Plastic straps may snap when cut off. There can be sharp edges, splinters, and nails on the crate and the equipment.


Wear personal protective equipment when handling the equipment during unpacking and installation. Handle the equipment with precaution. See Section *Personal protective equipment* in Chapter *Safety*.

A crate with crafted sides and top is assembled with boards.

1 Cut off the plastic bands and remove them.



2 Start with the top of the crate and remove one board at a time.



When the boards on the top are completely removed continue with the sides.

34 20000421-4-EN-GB

4.5.4 Inspection after uncrating

When the equipment is placed in its intended location, always perform the inspections listed below:

- Check the A measure.
- Make sure that all bolts are properly tightened.
- · Make sure that the stands and feet are properly tightened.



Some equipment is delivered with the stands disassembled.

- · Check that connection piping can be removed to perform service.
- · Make sure that there is enough space to remove plates on one side of the plate heat exchanger.

4.6 Lifting the equipment

It is recommended to engage the services of a rigging company to take care of all handling related matters until the equipment is in the position where it will be installed.

WARNING Risk of personal injury.

Equipment is heavy with a centre of gravity placed high.

Lifting and transport of the crated and uncrated equipment must be carried out by skilled persons. See Section Prior knowledge in Chapter Introduction.

WARNING

Risk of personal injury.

The equipment or loose objects can fall. Plastic straps may snap when cut off. There can be sharp edges, splinters, and nails on the crate and the equipment.

Wear personal protective equipment when handling the equipment during unpacking and installation. Handle the equipment with precaution. See Section Personal protective equipment in Chapter Safety.

WARNING

Risk of personal injury.

Never work under hanging load.

WARNING

Risk of personal injury.

Never work alone during lifting and handling of the crated or uncrated equipment.

The authorized personnel are always responsible for the safety, correct selection of lifting equipment and execution of the lifting and raising procedures. Use undamaged hoist slings approved for the weight of the plate heat exchanger. Use the lifting points as illustrated. If the equipment has lifting eve bolts, these must be used.

If otherwise not stated, use two hoist slings (1) and (2) and make sure that the lifting angle (α) is between 45° and 90°.





Figure 4: The illustration shows the threading of the hoist slings.

Place hoist slings according to picture in an angle β 45° to 90°.

36 200000421-4-FN-GB






Risk of damage to equipment.

If lifting is not possible according to this instruction, a risk assessment should be done by authorized personnel.

Crated equipment


When the equipment is crated it must be lifted in the delivered pallet using a forklift.



Disassemble equipment from pallet

Uncrate the equipment according to Section Installation - Unpacking the crate.


It is recommended to let the equipment remain assembled with the pallet and handle it using a forklift until it is time to install it.



Before loosening the equipment from the pallet, secure the equipment from falling using hoist slings.




Do not lift up the equipment and the pallet. Only stretch the hoist slings so the equipment will not fall.



Remove any attachment that assembles the equipment with the pallet.

Gently lift up the equipment and make sure that it releases from the pallet.



Uncrated equipment



CAUTION Risk of damage to equipment.

For hoist slings or for lifting devices always use the attachment points marked with red rings in the below figures. Use of other attachment points or strap load directions than those described are not allowed. If the plate heat exchanger is not supplied with lifting devices from Alfa Laval, the corresponding equipment must be selected and the same attachment points must be used. The authorized personnel have full responsibility for selecting components and procedures in a safe and correct way. Always be careful during the lifting procedure to avoid damage to the plate heat exchanger components.



Risk of damage to equipment.

Never lift by the connections or the stud bolts around them.

If the equipment is assembled with the delivered pallet, it must be lifted using a forklift.

If the equipment is disassembled from the delivered pallet, it must be lifted using hoist slings.




Figure 5: Lifting device for T35 and TS35. Securing equipment is needed.




Figure 6: Lifting device for T45, TL35 and WideGap 350. Securing equipment not needed.




Figure 7: Lifting device for T50. Securing equipment is needed.




Figure 8: Lifting device for TS50. Use the four inner eyes when lifting the plate heat exchanger. Do NOT use the transport securing points! Securing equipment is needed.

40 20000421-4-EN-GB



For detailed information contact an Alfa Laval sales representative for document "Cargo Securing Instructions" (3490003791, 3490003792, 3490003793).

4.7 Raising


This instruction is valid when raising the plate heat exchanger after delivery from Alfa Laval. Only use a strap approved for the weight of the plate heat exchanger. Follow the principle of the instruction below.

CAUTION


Risk of damage to equipment.

The hoist slings shall be long enough to be able to rotate the plate heat exchanger without obstruction. Consider especially the space for the support column. Always be careful during the raising procedure to avoid damage to the plate heat exchanger components.


1 Place two timber beams on the floor.




2 Lift the plate heat exchanger off the pallet using hoist slings.



3 Place the plate heat exchanger on the timber beams.




Place a hoist sling around one bolt on each side.






Lift the plate heat exchanger off the timber beams.



6 Lower the plate heat exchanger into a horizontal position and place it on the floor.



4.8 Inspection before installation

When the equipment is placed in its intended location, always perform the inspections listed below:

- · Check the A measure.
- · Make sure that all bolts are properly tightened.
- · Make sure that the stands and feet are properly tightened.
- Check that connection piping can be removed to perform service.
- Make sure that there is enough space to remove plates on one side of the plate heat exchanger.

44 200000421-4-EN-GB

5 Operation

5.1 Start-up

During the start-up, check that there are no visible leakages from the plate pack, valves or piping system.



Before pressurizing the plate heat exchanger, it is important to ensure that the temperature of the plate heat exchanger is within the temperature range as stated in the PHE drawing.

CAUTION

Risk of leakage.

If the temperature of the plate heat exchanger is below the minimum temperature for the gaskets prior to the service, it is recommended to heat the plate heat exchanger above this limit to avoid cold leakage.



If several pumps are included in the system, make sure you know which one should be activated first.

Centrifugal pumps must be started with valves closed and the valves must be operated as smoothly as possible.


Do not run pumps temporarily empty on the suction side.

● NOTE


Adjustments of flow rates should be made slowly in order to avoid the risk of pressure surge (water hammer).

Water hammer is a short lasting pressure peak that can appear during the start-up or shut-down of a system, causing liquids to travel along a pipe as a wave at the speed of sound. This can cause considerable damage to the equipment.


Before start-up, check that all the tightening bolts are firmly tightened and that the **A** measure is correct. See the PHE drawing.



Check that the valve is closed between the pump and the unit controlling the system flow rate to avoid pressure surge.




- (3) If there is a vent valve installed at the exit, make sure it is fully open.
- (4) Increase the flow rate slowly.
- (5) Open the air vent and start the pump.




6 Open the valve slowly.



Avoid rapid temperature changes in the plate heat exchanger. With media temperatures over 100 °C, slowly increase the temperature, preferably at least for one hour.



When all the air is expelled, close the air vent.



8 Repeat the procedure for the second media.

5.2 Unit in operation

Adjustments of flow rates should be made slowly in order to protect the system against sudden and extreme variations of temperature and pressure.

During operation, check that media temperatures and pressures are within the limits stated on the name plate and the PHE drawing.




In case of failures that endanger safety operation, turn off the flows to the plate heat exchanger in order to decrease the pressure.

5.3 Shut-down



If several pumps are included in the system, make sure you know which one should be stopped first.


Slowly close the valve controlling the flow rate of the pump you are about to stop.



- **2**) When the valve is closed, stop the pump.
- Repeat the two steps for the other side for the second media.
- If the plate heat exchanger is shut down for several days or longer, it should be drained. Draining should also be done if the process is shut down and the ambient temperature is below the freezing temperature of the media. Depending on the media processed, it is also recommended to rinse and dry the plate heat exchanger plates and connections.



Avoid vacuum in the plate heat exchanger by opening vent valves.



6 Maintenance

To keep the plate heat exchanger in good condition, regular maintenance is required. It is recommended to record all maintenance of the plate heat exchanger.

The plates need to be cleaned on a regular basis. The frequency depends on several factors such as type of media and temperature.

Different methods can be used for cleaning (see Procedure *Cleaning – Non-product side* on page 50) or reconditioning can be performed at an Alfa Laval service center.

After a long period of use, it can be required to regasket the plate heat exchanger. See Procedure *Regasketing* on page 64.

Other maintenance that should be performed regularly:

- · Keep the carrying bar and guiding bar clean and grease.
- · Keep the tightening bolts cleaned and greased.
- Check that all the tightening bolts are firmly tightened and that the dimension A is correct. See the PHE drawing.

6.1 Cleaning - Non-product side

The cleaning-in-place (CIP) equipment permits cleaning of the plate heat exchanger without opening it. The purpose of cleaning with CIP is as follows:

- Cleaning of fouling and descaling of lime deposits
- Passivation of cleaned surfaces to reduce susceptibility to corrosion
- Neutralization of cleaning liquids before draining

Follow the instructions of the CIP equipment.

WARNING

Risk of personal injury.

Use proper personal protective equipment when using the cleaning agents. See Section *Personal protective equipment* in Chapter *Safety*.

↑ WARNING

Risk of personal injury.

Corrosive cleaning liquids. Can cause serious injuries to skin and eyes.

Use proper personal protective equipment. See Section *Personal protective equipment* in Chapter *Safety*.

CIP equipment

Contact an Alfa Laval sales representative for the size of CIP equipment.



№ WARNING

Risk of personal injury.

The residuals after a cleaning procedure shall be handled according to local environmental regulations. After neutralization most cleaning solutions may be drained into the waste water system under the condition that the fouling deposits do not contain heavy metals or other toxic or environmentally dangerous compounds. Prior to disposal, it is recommended to analyze the neutralized chemicals for any hazardous compounds that were removed from the system.

Cleaning liquids

Liquid	Description			
AlfaCaus	A strong alkaline liquid, for removing paint, fat, oil and biological deposits.			
AlfaPhos	An acid cleaning liquid for removing metallic oxides, rust, lime and other inorganic scale. Contains repassivation inhibitor			
AlfaNeutra	A strong alkaline liquid for neutralization of AlfaPhos before drainage.			
Alfa P-Neutra	For neutralization of Alfa P-Scale.			
Alfa P-Scale	An acidic powder cleaner for the removal of primary carbonate scale but also other inorganic scale.			
AlfaDescalent	A non-hazardous acidic cleaning agent for the removal of inorganic scale.			

50 200000421-4-EN-GB

Liquid	Description	
AlfaDegreaser	A non-hazardous cleaning agent for the removal of oil, grease or wax deposits. Also prevents foaming when using Alpacon Descaler.	
AlfaAdd	AlfaAdd is a neutral cleaning strengthener designed to be used with AlfaPhos, Alfa-Caus and Alfa P-Scale. 0.5–1 vol% is added to the total diluted cleaning solution to provide better cleaning results on oily and fatty surfaces and where biological growth occurs. AlfaAdd also reduces any foaming.	

If CIP cannot be done, cleaning must be done manually. See Section Manual cleaning of opened units on page 57.

Chlorine as a growth inhibitor

Chlorine, commonly used as a growth inhibitor in cooling water systems, reduces the corrosion resistance of stainless steels (including high alloys like Alloy 254).

Chlorine weakens the protection layer of these steels making them more susceptible to corrosion attacks then they otherwise would be. It is a matter of time of exposure and concentration.

In all cases where the chlorination of non-titanium equipment cannot be avoided, your local representative must be consulted.

Water of more than 330 ppm Cl ions may not be used in the preparation of cleaning solutions.



CAUTION Risk of personal injury.

Ensure that the handling of residuals after using chlorines follow local envionmental regulations.

6.2 Opening

During manual cleaning, it is necessary to open the plate heat exchanger to clean the plates.



Before opening the plate heat exchanger, check the warranty conditions. If in any doubt, contact the Alfa Laval sales representative. See Section *Warranty conditions* in Chapter *Introduction*.

MARNING

Risk of personal injury.

The plate heat exchanger can be hot.

Wait until the plate heat exchanger has cooled down to about 40 °C (104 °F).


MARNING


Risk of personal injury.

Use proper protective equipment. See Section *Personal protective equipment* in Chapter *Safety*.

6.2.1 Bolt configuration

The bolt configuration of the plate heat exchanger varies between different models. The major force of the plate pack is held by the tightening bolts (TB). To distribute the force evenly over the frame plate and pressure plate, locking bolts (LB) are used as well. The locking bolts can be shorter and can have smaller dimensions. In the opening and closing procedure, it is important to identify the tightening bolts (TB) and the locking bolts (LB). See the illustration below.





6.2.2 Opening procedure

- Shut down the plate heat exchanger.
- 2 Close the valves and isolate the plate heat exchanger from the rest of the system.




The plate heat exchanger must be pressureless before disconnecting it.


(3) Drain the plate heat exchanger.




Avoid vacuum in the plate heat exchanger by opening vent valves.




- If there are any protection sheets, remove them.
- (5) Disassemble pipes from the pressure plate so that the pressure plate are free to move along the carrying bar.
- 6 Inspect the sliding surfaces of the carrying bar. Wipe the sliding surfaces clean and put grease on them.



7) Mark the plate assembly on the outside with a diagonal line.




Check and note the A measure.




(9) Only valid for T50 and TS50. Loosen and remove the locking device. Save the the locking device for reassembling.

Only valid for TL35, T50 and TS50. Loosen and remove the feet at pressure plate.


Remove the nuts of the foundation bolts located at the outside.




Remove the nuts and bolts that connect the feet against the pressure plate.



Remove the outer feet. The pressure plate has a slot which makes it possible to pass the protruding foundation bolt.




Only valid for T35, TS35, and T45. Loosen and remove the feet at pressure plate.
Loosen the nuts of the foundation bolts located at the outside. Remove the nuts and bolts that connect the feet against the pressure plate. Rotate the outer feet.




Loosen and remove the locking bolts. Identify them according to *Bolt configuration* on page 52.




Brush the threads of the tightening bolts with a steel wire brush and then grease the threads before loosening the tightening bolts.





Use the tightening bolts, equipped with bearing boxes, to open the plate heat exchanger. During the opening procedure, keep the frame plate and pressure plate parallel. Skewing of the pressure plate during opening must not exceed 10 mm (2 turns per bolt) across the width and 25 mm (5 turns per

Loosen the four tightening bolts (1), (2), (3), (4) or the six tightening bolts (1), (2), (3), (4), (5), (6) diagonally until the plate pack measure is 1.05×A making sure that the frame plate and pressure plate are parallel while opening. Continue alternating between each bolt until all reaction forces of the plate pack have disappeared. Then remove the bolts






↑ CAUTION

bolt) vertically.

Risk of personal injury.

Plates and protection sheets has sharp edges.


Wear personal protective equipment when handling the plates and the protection sheets. See Section *Personal protective equipment* in Chapter *Safety*.



Open the plate pack by letting the pressure plate glide on the carrying bar.

If plates are to be numbered, do this before removing the plates.

Plates need not be removed if cleaning is done using only water, i.e. without a cleaning agent.





Risk of personal injury.

The plate pack may still contain a small residual amount of liquid after draining.

Depending on the type of product and type of installation, special arrangements like a drainage box, may be necessary to use to avoid injury to personnel and damage to equipment.

56 20000421-4-EN-GB

6.3 Manual cleaning of opened units

CAUTION

Never use hydrochloric acid with stainless steel plates. Water of more than 330 ppm Cl may not be used in the preparation of cleaning solutions.

It is very important that aluminium carrying bars and support columns are protected against chemicals.



Be careful not to damage the gasket during manual cleaning.

WARNING

Risk of personal injury.

Use proper personal protective equipment when using the cleaning agents. See Section Personal protective equipment in Chapter Safety.

WARNING

Risk of personal injury.

Corrosive cleaning liquids. Can cause serious injuries to skin and eyes.

Use proper personal protective equipment when using the cleaning agents. See Section Personal protective equipment in Chapter Safety.

6.3.1 Deposits removable with water and brush

Plates do not need to be removed from the plate heat exchanger during cleaning.

- Start cleaning when the heating surface is still wet and the plates are hanging in the frame.
- Remove deposits using a soft brush and running water.



Rinse with water using a high pressure hose.




6.3.2 Removal, lifting and insertion of plates in the field


1 Open the plate pack by letting the pressure plate glide on the carrying bar. Each plate shall be removed one by one, preferably by one person on each side of the plate. For safe removal and lifting of large plates type T50, TS50 and T45 a lifting device shall be used.



Lifting of a single plate shall be done in a controlled way. Insert the plates with the herring bone pattern positioned in alternate directions and with the gaskets turned towards the frame plate.



The plate package shall be pressed towards the frame plate in steps, preferably by using a Pusher towards the upper part of the plate.



MARNING

If hard winds or risk of contamination of the plates the removal shall be made in restricted and safe environment.

To avoid sharp edges protective gloves should always be worn.

Lifting in edges around the portholes shall be avoided.

6.3.3 Deposits not removable with water and brush

Plates must be removed from the plate heat exchanger during cleaning. For a choice of cleaning agents, see Section *Cleaning liquids* on page 50.

58 20000421-4-EN-GB

1 Brush with cleaning agent.



2 Rinse immediately with water.



Long exposure to the cleaning agents can damage the gasket glue.




6.4 Closing

Follow the instructions below to ensure that the plate heat exchanger will be properly closed.

For bolt identification, see Section Bolt configuration on page 52.

- 1 Check that all the sealing surfaces are clean.
- 2 Brush the threads of the bolts clean, using a steel wire brush or the Alfa Laval thread cleaner. Lubricate the threads with a thin layer of grease, for example Gleitmo 800 or equivalent.




Attach the gaskets to the plates or check that all gaskets are properly attached. Check that all gaskets are correctly positioned in the grooves.





If the gasket is wrongly positioned, it will show by the fact that it rises out of the gasket groove or that it is positioned outside the groove.

If the plates have been removed, insert them in alternate directions and with the gaskets turned towards the frame plate or pressure plate as specified on the plate hanging list. Use the marked line that was made when the plate heat exchanger was opened, see Procedure Opening - Procedure.



5 If the plate pack has been marked on the outside, check this according to Procedure Opening - Procedure. If the plates are correctly assembled (A/B/A/B etc.), the edges form a "honeycomb" pattern, see picture.






6 Press the plate pack together. Use the tightening bolts equipped with bearing boxes, to close the plate heat exchanger. Position the four or six tightening bolts according to the illustration.

Tighten the four bolts (1), (2), (3), (4) or the six bolts (1), (2), (3), (4), (5), (6) until the plate pack measure is $1.20 \times \mathbf{A}$ making sure the frame plate and pressure plate are parallel when closing.


Tighten the four bolts (1), (2), (3), (4) or the six bolts (1), (2), (3), (4), (5), (6) until the plate pack measure is $1.10 \times \mathbf{A}$ making sure the frame plate and pressure plate are parallel when closing.



7 Tighten the four bolts (1), (2), (3), (4) or the six bolts (1), (2), (3), (4), (5), (6) evenly until **A** measure has been reached.

When a pneumatic tightening device is used, see table below for maximum torque. Check the **A** measure during tightening.


Bolt size	Bolt with bearing box		Bolt with washer	
	Nm	kpm	Nm	kpm
M39	1300	130	2000	200
M48	2100	210	3300	330
M52	2100	210	3300	330



For manual tightening, the tightening torque has to be estimated.

If the **A** measure cannot be reached:

- Check the number of plates and the A measure.
- Check that all the nuts and bearing boxes are running freely. If not, clean and lubricate, or replace.
- 8 Assmeble the remaining locking bolts and check the **A** measure on both sides, top, and bottom.



- 9 Install protection sheets (if provided).
- 10 Connect the pipes.
- If the plate plate heat exchanger does not seal when the **A** measure has been reached, it can be tightened further to the given **A** measure value minus 1.0%.
- 12 Assemble the feet to the pressure plate.
- For T50 and TS50 assemble the locking device.

62 20000421-4-EN-GB

6.5 Pressure test after maintenance

Neither of these processes are allowed unless performed by a person authorized according to local laws and regulations and following applicable standards. If no such person is internally available, a third party authorized entrepreneur working per local legislation using proper equipment shall be engaged.

Before the start-up of production, whenever plates or gaskets have been removed, inserted or exchanged, it is strongly recommended to perform a hydrostatic leakage test to confirm the internal and external sealing function of the plate heat exchanger. In this test, one media side at a time must be tested with the other side open to the ambient pressure. In a multi-pass set up, all sections of the same side must be tested simultaneously. The recommended test time is 10 minutes for each media side.



Risk of damage to equipment.

The recommended pressure for the leakage test is a pressure equal to the operating pressure + 10% of the actual unit but never above the allowable pressure (PS) as stated on the name plate.



Rik of personal injury.

Testing by putting gas (compressible media) under pressure can be very dangerous. Local laws and regulations regarding to the hazard involved in testing with a compressible medium must be respected. Hazardous examples are explosion risk due to uncontrolled medium expansion and/or suffocation risk due to oxygen depletion.

MARNING

Risk of damage to equipment.

Any rebuilding or modification of the plate heat exchanger is the responsibility of the end user. Regarding recertification and pressure test (PT) of the plate heat exchanger the local laws and regulations for in service inspection must be respected. Example of a rebuilding is that more number of plates are added to the plate pack.

If there is any uncertainty about the testing procedure of the plate heat exchanger, consult an Alfa Laval representative.

6.6 Regasketing

The procedures below concern field gaskets, ring gaskets and end gaskets.



Before removing the old gaskets, check how they are attached.

6.6.1 Clip-on / ClipGrip

1 Open the plate heat exchanger, see Section Opening on page 52, and remove the plate that is to have a new gasket.



Before opening the plate heat exchanger, check the warranty conditions. If in any doubt, contact the Alfa Laval sales representative. See Section *Warranty conditions* in Chapter *Introduction*.

- (2) Remove the old gasket.
- Make sure that all sealing surfaces are dry, clean and free of foreign matter such as fat, grease or similar.
- 4 Check the gasket and remove rubber residual before attaching it.




Especially the end plate gasket!

(5) Attach the gasket to the plate. Slip the gasket tabs under the edge of the plate.



Make sure the two gasket prongs are in the correct position.



Repeat the procedure on all the plates that needs to be regasketed. Close the plate heat exchanger according to *Closing* on page 60.

6.6.2 Base-ad gaskets

The Base-ad gasket represents a system with fastening by means adhesive tape.

The use of the adhesive tape (GC1) is a simple way to obtain secure gasket positioning. It is adhered to the gasket groove by means of a special tape gun, making it easy to apply the tape exactly where wanted.






Before opening the plate heat exchanger, check the warranty conditions. If in any doubt, contact an Alfa Laval sales representative. See Section Warranty conditions in Chapter Introduction.

Open the plate heat exchanger (see Section Opening) and remove the plate that is to have a new gasket.

- (2) Remove the old gasket.
- 3) It is not necessary to remove old tape as the film is very thin. Make sure, however, that the gasket groove is clean and dry.
- Adhere tape, using the tape gun.



- Attach the gasket to the plate.
- Close the plate heat exchanger, see Section Closing.

6.6.3 Glued gaskets

Use glue recommended by Alfa Laval. Separate gluing instructions will be delivered together with the glue.



Other glues than those recommended can contain chlorides that can damage the plates.



Do not use sharp tools when removing the glued gasket to avoid damage to the plates.

66 200000421-4-EN-GB

7 Storage of the plate heat exchanger



MARNING Risk of damage to equipment.

The crate is not designed to be stacked.

Never put a load on top of the crate.

Alfa Laval delivers the plate heat exchanger ready to be put into service upon arrival, if nothing else has been agreed.

If storing for longer periods of time, such as one month or longer, certain precautions should be made to avoid unnecessary damage to the plate heat exchanger. See Sections Outdoor storage on page 67 and Indoor storage on page 67.



Alfa Laval and its representatives reserve the right to inspect the storage space and/or equipment whenever necessary until the expiration of the warranty period stipulated in the contract. Notification must be given 10 days prior to the date of inspection.

If there is any uncertainty about the storage of the plate heat exchanger, consult an Alfa Laval representative.

7.1 Storage in crate

If storage of the plate heat exchanger after delivery is known in advance, inform Alfa Laval when ordering the plate heat exchanger to ensure that it will be properly prepared for storage before packing.

Indoor storage

- Store inside a room with the temperature between 15 and 20 °C (60 and 70 °F) and humidity up to 70%. For outdoor storage read Outdoor storage on page 67.
- To prevent damage to the gaskets, there should not be any ozoneproducing equipment in the room such as electric motors or welding equipment.
- To prevent damage to the gaskets, do not store organic solvents or acids in the room and avoid direct sunlight, intensive heat radiation or ultraviolet radiation.
- The tightening bolts should be well covered with a thin layer of grease. See Section *Closing* on page 60.

Outdoor storage

If you need to store your plate heat exchanger outdoors, follow all the precautions in *Indoor storage* on page 67 as well as the precautions listed below.

The stored plate heat exchanger shall be visually checked every third month. When closing the packing it shall be restored to original condition. The check includes:

200000421-4-FN-GB 67

- Greasing of the tightening bolts
- · Metal port covers
- · Protection of the plate pack and gaskets
- · The packing

7.2 Taken out of service

If, for any reason, the plate heat exchanger is shut down and taken out of service for a long period of time, follow the precautions in *Indoor storage* on page 67. However, before storage the following actions must be done.

- Check the measurement of the plate pack (measure between frame plate and pressure plate, the **A** measure).
- · Drain both media sides of the plate heat exchanger.
- Depending on media, the plate heat exchanger should be rinsed and then dried.
- The connection should be covered if the piping system is not connected.
 Use a plastic or plywood cover for the connection.
- Cover the plate pack with non-transparent plastic film.

Start-up after long-term out of service

If the plate heat exchanger has been taken out of service for an extensive period of time, longer than one year, the risk of leakage when starting up increases. To avoid this problem it is recommended to let the gasket rubber rest to regain most of its elasticity.

- **1.** If the plate heat exchanger is not in position, follow the instructions in *Installation* on page 23.
- 2. Note the measurement between frame plate and pressure plate (the A measure).
- 3. Remove the feet attached to the pressure plate.
- **4.** Loosen the tightening bolts. Follow the instructions in *Opening* on page 52. Open the plate heat exchanger until the plate pack measure is 1.25×**A**.
- **5.** Leave the plate heat exchanger for 24–48 hours, the longer the better, for gaskets to relax.
- **6.** Re-tighten according to the instructions in *Closing* on page 60.
- 7. Alfa Laval recommends a hydraulic test should be carried out. The media, usually water, should be entered at intervals to avoid sudden shocks to the plate heat exchanger. It is recommended to test up to the Design Pressure. See the PHE drawing.

68 200000421-4-EN-GB